ENHANCING CARPET AND VELOUR

SEM PREP MATERIALS

ADDITIONAL PREPITEMS

SEM REFINISHING SYSTEM



3835() PLASTIC/LEATHER PREP



Nylon bristle brush



Upholstery shampoo or Carpet shampoo



COLOR COAT

NOTE: COLOR COAT is recommended only to enhance the color of carpet and velour, not to drastically change its color. Trying to do so may adversely affect the texture of the carpet or velour. COLOR COAT is not suitable for long nap, shag carpets.

1 Clean velour with a good quality upholstery shampoo. Clean carpet with a good quality carpet shampoo. Allow to dry.





3 Apply 2 light coats of COLOR COAT (see page 6) allowing 3-5 minutes flash time between coats. Immediately after each coat, brush in all directions with a nylon brush to keep the fibers separated.



2 Next, clean with 3835() PLASTIC/LEATHER PREP. Scrub lightly with a nylon bristle brush to remove oil, grease and contaminants. Allow surface to dry and then vacuum.

CAUTION: Make certain surface is dry before applying **COLOR COAT**.

4 Allow last coat to dry 5-10 minutes. Brush surface again in all directions to make certain fibers are separated, then vacuum.